

# Instructions for Use with Conect-A-Kit Fittings LJ-3044 VersaTool™

1. Locate and mark the 1/4" dia. lag bolt pilot hole on the end of the handrail or rail drop using the 1 1/8" tabs on the VersaTool™. Sight the handrail centerline\* thru the hole in the installer tool.

2. Use the socket-head end of the tool to tighten lag bolts for assembling Conect-A-Kit fittings.

\*Use the groove machined into the bottom of our non-plowed profiled handrails. All other handrails will require marking a centerline on the bottom of the handrail.

